

- 1. GRIP INSTALLATION: START GRIP ON CLEAN, DRY BAR, IN DESIRED POSITION, AND BUMP ON WITH THE PALM OF YOUR HAND OR ANY SUITABLE DEVICE SUCH AS A MALLET, UNTIL THE GRIP IS ALL THE WAY ON THE BAR. DO NOT USE ANY LUBRICANTS WHATSOEVER. THIS INCLUDES WATER, SOAP, OID, SILICONE, POWDERS, ETC. DO NOT USE COMPRESSED AIR (MAY CONTAIN MOISTURE AND OIL). JEST AFTER INSTALLATION TO SEE IF GRIPS ARE TIGHT. DO NOT USE GRIPS IF THEY ARE NOT TIGHT. REPLACE GRIPS THAT BECOME WORN OR LOOSE.
- 2. (WINCHE'S USING THE OUTER HOLE PATTERN): ATTACH HANDLES TO WINCH MOUNTING PLATFORM OUTER HOLE PATTERN USING WINCH MANUFACTURERS HARDWARE AND INSTRUCTIONS. (WINCHES USING THE INNER HOLE PATTERN): ATTACH HANDLES TO WINCH MOUNTING PLATFORM OUTER HOLE PATTERN USING HANDLE KIT SUPPLIED HARDWARE.
- 3. IF USING FAIRLEAD, ATTACH USING THE MANUFACTURERS INSTRUCTIONS.
- 4. INSTALL THE WINCH AND PLATFORM IN THE RECEIVER AND PIN IN THE STANDARD ATTACHMENT HOLE AS SHOWN ABOVE. USE THE SECONDARY ATTACHMENT HOLE ONLY IF VEHICLE/WINCH CONFIGURATION DOES NOT ALLOW CLEARANCE FOR STANDARD ATTACHMENT HOLE.