

INSTALLATION INSTRUCTIONS

EQUIPMENT REQUIRED:

WIRING ACCESS LOCATION: SUV7

DRILL BITS:


HITCH REQUIRES 1/2" PIN & CLIP

WRENCHES: (TIGHTEN ALL FASTENERS WITH TORQUE WRENCH) 7/8, 18mm

VEHICLE

CHEVROLET BLAZER
GMC JIMMY
OLDSMOBILE BRAVADA
GMC ENVOY

3500 LB MAX GROSS TRAILER WT
300 LB MAX TONGUE WEIGHT
DO NOT EXCEED TOWING VEHICLE RATINGS



HITCH SHOWN IN PROPER POSITION

FASTENERS TYPICAL
BOTH SIDES


VEHICLE FRAME

1/2-13 X 1-3/4 GR5
CARRIAGE BOLT
1/4 X 1-1/2 X 2 BLOCK
LOCK WASHER
NUT

NOTE: ON 98 AND NEWER MODELS, REMOVE FORWARD BUMPER BOLTS (4) AND RETURN TO VEHICLE OWNER.

1. LOOSEN SPARE TIRE (IF STORED UNDER VEHICLE) TO ALLOW MOVEMENT FRONT TO REAR.
2. RAISE HITCH INTO POSITION AND INSTALL THREE (3) 1/2-13 X 1-3/4 CARRIAGE BOLTS, BLOCKS, LOCK WASHERS AND NUTS AS SHOWN, EACH SIDE.
NOTE: POSITION BLOCKS AS SHOWN ABOVE.
3. RE-TIGHTEN SPARE TIRE.

TIGHTEN 1/2 GR5 FASTENERS TO 75 LB.-FT.



USE ONLY THE DRAWBAR SHOWN FOR CORRECT BUMPER CLEARANCE AND HEIGHT.
DRAWBAR MUST BE USED IN THE RISE POSITION ONLY.

THIS PRODUCT COMPLIES WITH SAFETY SPECIFICATIONS AND REQUIREMENTS FOR CONNECTING DEVICES AND TOWING SYSTEMS OF THE STATE OF NEW YORK, V.E.S.C. REGULATION V-5 AND SAE J684.

APPROX WEIGHT (LB.)
23.5

FASTENER KIT
01130-944

NOTE: Check hitch frequently, making sure all fasteners and ball are properly tightened. If hitch is removed, plug all holes in trunk pan or other body panels to prevent entry of water and exhaust fumes. A hitch or ball which has been damaged should be removed and replaced. Observe safety precautions when working beneath a vehicle and wear eye protection. Follow car maker's specs for maximum trailer weight and tongue weight. Do not cut access or attachment holes with a torch.

TOWING PRODUCTS
Plymouth, Michigan

PRINTED IN MEXICO