

# OPERATING INSTRUCTIONS

## Elite Series


### 26.5K 5TH WHEEL HITCH

#### DEALER/INSTALLER:

- (1) Provide this Manual to end user.
- (2) Physically demonstrate hitching and unhitching procedures in this Manual to end user.
- (3) Have end user demonstrate that he/she understands procedures.

#### END USER:

- (1) Read and follow this Manual every time you use hitch.
- (2) Save this Manual and Hitch Warning Hang Tag for future reference.
- (3) Pass on copies of Manual and Hitch Warning Hang Tag to any other user or owner of hitch.
- (4) Never remove hitch warning decals as shown in Figure 31 of this manual. If damaged, contact Cequent Performance Products (1-800-632-3290 ) for free replacement.



**For Installation Assistance or Technical Help, Call 1-800-632-3290**

**⚠ WARNING:**

**Failure to follow all of these instructions may result in death or serious injury**

**INDEX**


1. BEFORE EACH TRIP	P. 2	7. HITCHING PROCEDURE	P. 12
2. LUBRICATION	P. 3	8. PULL TEST	P. 14
3. ASSEMBLY / ADJUSTMENT	P. 4	9. UNHITCHING PROCEDURE	P. 15
4. HITCH INSTALLATION	P. 8	10. MAINTENANCE	P. 15
5. HITCH REMOVAL	P. 8	11. PARTS EXPLOSION	P.16
6. GUIDELINES FOR MATCHING HITCH	P. 9	12. LIMITED LIFETIME WARRANTY	P.17

**GUIDELINES FOR MATCHING HITCH TRUCK AND TRAILER**

If preparing to tow a 5th wheel trailer which you have not rating checked previously, please consult Figure 16 of Elite Series assembly instructions to verify proper ratings.

**BEFORE EACH TRIP:**

1. Lubricate skid plate surface of the hitch and pivot pin grease fitting (see Figure on cover of Manual) with automotive type chassis grease or use a plastic lube plate to provide a lubricated surface. Use lithium grease to lubricate pivot points of moving parts within the hitch.
2. Plastic lube plates (Towing Products No. 83001) can be used to avoid messy grease. The plastic lube plate must not exceed 3/16 of an inch in thickness to ensure hitch will operate properly. **Lube plate must be 12 inches in diameter or larger to properly distribute king pin weight.**
3. Before each trip or maneuver, operate the handle and check that the jaw opens and closes freely.
4. See that all hitch pull pins (# 14, Figure 31) are in place and the spring retaining clips (#15, Figure 31) are installed (Figure 1). Note that hitch pull pins used with the Elite Series Hitch are 90 degree bent pins and if replacements are needed, please contact the factory. Check that all four anchor assembly handles are lynch pinned/locked through base arch shell.




**⚠ WARNING:**  
To prevent tilting head detachment and or separation of hitch you must make sure that the anchor assemblies are properly installed and pinned, and the spring retaining clips are properly installed onto the 1/2" pull pins before towing. The spring retaining clips can easily be seen through the site holes in the top of the head.

**Figure 1 : Pins and Clips (Skid Plate cut away view)**



**LUBRICATION:**

1. Lube center section as shown in Figure 2 with lithium grease.
2. Lube pins (2) and slide bar opening as shown in Figure 3 with lithium grease prior to installation/operation.
3. Lube feet with lithium grease for easier engagement as shown in Figure 4.



**•Figure 2: Lubrication Points**

**•Figure 3: Pin/Lube Points (Bottom View)**



**•Figure 4: Lube Points**

## Elite Series Fifth Wheel Assembly / Adjustment


### TOOLS

7/16", 9/16" and 1-1/8" Socket & Open End Wrench  
300 ft-lb Torque Wrench  
1-1/2" Box End Wrench


1. Check box for all components listed in Figure 1 and become familiar with component terminology. Center section, Arches, and Anchor assemblies may be packed assembled. If already assembled start at Step 7. Use this section if you need to adjust your assembly in the future.
2. NOTE A : Hole positions used in assembly will need to be chosen based on the head height measurements taken previously. Choose calculated height closest to one of the following height dimensions: 15-3/4" (top hole), 17" (2<sup>nd</sup> hole down), 18-1/4" (bottom hole)

NOTE B : The fore/aft position of the head relative to the tow vehicle axle can be adjusted by 1-1/2" based on the position of the center section (Figure 6). See note in figure 6.

NOTE C : Base arch with the larger label must be positioned on the Driver's side of the vehicle.



3. Place assembly into mounting pucks which are installed in truck (see Elite Series Mounting Kit Instructions). (Figure 7). Be sure that base arches are contacting all pucks with bushings slid into puck slots.
4. Tighten 3/4 bolts in center section to 260 lb-ft. using 1-1/8" socket. Snug tight (no vertical play in anchor bushing assembly) all (4) 1" jam nuts inside base arches using a 1-1/2" box end wrench, then tighten each jam nut another 1/4 turn for proper torque requirement. Note that the unit is not secured down and should be held while tightening hardware.



**Figure 7: Placement in Mounting Kit / Truck Bed**


5. Lift unit out of pucks. There should be minimal resistance. If there is some resistance, or you can not drop the unit back into the pucks, the unit should be adjusted; loosen 1" nuts and Center Section bolts and repeat Steps 3 & 4.

**⚠ WARNING:**  
Failure to properly install handles could result in tow vehicle damage or truck and trailer separation.


6. Replace unit into pucks with all handles in unlocked position (see Figures 8A and 8B). Rotate handles into locked position. It is normal for some of the handles to have very little or no resistance; while others have a moderate amount of resistance when locking. Should a handle not be able to be locked by hand it needs to be adjusted, see Note D.

NOTE D: To adjust handle tension when locking first remove hitch from pucks. Next, while keeping the handle to tee pin orientation, remove the lynch pin. Rotate the tee pin counterclockwise 1/2 rotation, and replace lynch pin. Conversely, if there is too much clearance in the attachments when locked, the clearance can be removed by rotating the tee pin clockwise 1/2 rotation, and replacing the lynch pin.

7. Remove hitch assembly and lube (lithium grease) tee pins in bushings, replace unit in pucks.
8. Lock handles through arches on both sides and place lynch pins through overlapping handle holes (see Figure 9).




**Figure 8A: Anchor Handles in Unlocked Position**




**Figure 8B: Anchor Handles in Locked Position (overlapped)**

Locking Hole Tabs in Handles overlap and Protrude through Base Arch

**Figure 9: Pinning Anchor Handles**




10. If not already installed the Left hand and Right hand torsion springs will need to be added to the center section so that the coil is facing the rear of the truck and wide hook sits over casting as shown in Figure 10. Tighten 1/4-20 X 1 1/2 BOLT with 7/16 socket to 8 ft.lbs.




**Figure 10: Torsion Spring Assembly**

11. Place and pin head onto center section (see Figures 11/12). Keep hands clear of ear placement while placing/removing head on/off hitch base as noted on head labels. Head will tilt rearward with proper torsion spring installation (Step 10).
12. Add head handle and handle carriage bolts as shown in Figure 11.
13. Slide handle grip over handle tube (using liquid soap as a lubricant will ease installation).
14. Lube jaw and skid plate (If no lube plate is being used) with automotive type chassis grease (see Figure 12). The jaw pin comes greased from the factory. To insure smooth jaw operation, grease should be added every 6 months to grease fitting on top of head (see Figure 12). Refer to the Lubrication section in this manual.



**Figure 11 : Head Placement**



**WARNING:**  
 To prevent tilting head detachment and or separation of hitch you must make sure that the anchor assemblies are properly installed and pinned, and the spring retaining clips are properly installed onto the 1/2" pull pins before towing. The spring retaining clips can easily be seen through the site holes in the top of the head.


**Figure 12 : Pin and Clip (Skid Plate cut away view)**

## **HITCH INSTALLATION:**

1. Remove puck plugs from all (4) of the pucks in the truck bed (Figure 13) and store for use when hitch is removed.
2. Set Elite Series hitch onto the pucks, and rotate handles into unlocked position (approximately perpendicular with base arch, Figure 14) until hitch drops into pucks on all (4) corners.
3. Rotate (4) handles into locked position (with locking holes through base arch shell) and overlapped on each side (Figure 15).
4. Place lynch pins / locks through the overlapping handle holes on each side to anchor hitch into pucks (Figure 15).
5. KEEPING HANDS AND FINGERS AWAY FROM THE PINCH POINTS ON EACH SIDE OF THE HEAD, place head onto center section (Figure 11). Head should tilt rearward on the torsion springs.
6. Insert pull pin and clip on each side of the head to attach to the hitch center section (Figure 12).
7. Pull up on head to test that all attachments have been completed properly and hitch is ready to tow.

## **HITCH REMOVAL:**

1. Remove pull pin and clip from each side of the head (Figure 12).
2. KEEPING HANDS AND FINGERS AWAY FROM THE PINCH POINTS ON EACH SIDE OF THE HEAD, lift head off center section (Figure 11). Store where dirt and debris will not get inside jaw mechanism.
3. Remove lynch pin / lock from the overlapping handle holes on each side of the hitch (Figure 15). Store lynch pins.
4. Rotate (4) handles into unlocked position (perpendicular with base arch shell, Figure 14). Lift each side of hitch out of pucks separately, handles may have to be jiggled slightly to align anchors with puck holes to remove.
5. Store hitch in dry place where dirt and debris will not get into anchor assemblies.
6. Press puck plugs (packed with mounting kit) into all (4) of the pucks in the truck bed to keep debris out of pucks (Figure 13).



**WARNING:**



Failure to follow all of these instructions may result in death or serious injury!


**GUIDELINES FOR MATCHING HITCH, TRUCK, AND TRAILER**

**WARNING:**

Failure to check and follow tow ratings could result in tow vehicle damage or truck and trailer separation while towing.

- Trailer and its contents together must not exceed truck, hitch and/or trailer tow ratings.
- Towing vehicle must have a manufacturer's rated towing capacity equal to or greater than the gross trailer weight (dry weight of the trailer plus payload of the trailer). (See Fig. 16)
- Gross weight of trailer must not exceed 26,500 lbs.
- King pin weight must not exceed 6625 lbs. If in doubt have king pin weight measured by qualified facility.

**Figure 16**




1. Check Tow Ratings:

Vehicle Tow Rating: \_\_\_\_\_  
 Elite Series Hitch Rating: 26,500 lbs.  
 Gross Trailer Weight (Figure 16): \_\_\_\_\_

\*Trailer weight should be the lowest of these recorded ratings for safe towing conditions.

2. Cequent Performance Products hitches are designed for use with recreational fifth wheel trailers only. Hitch applications other than recreational fifth wheel trailers must be approved in writing by Cequent Performance Products' Engineering Department.
3. Use only a SAE 2-inch king pin with your Elite Series Fifth Wheel Hitch.
4. Approximately 15%-25% of trailer weight should be on hitch (Pin Weight). See Fig. 17.


**Figure 17**



5. Trucks come in many different configurations. Cequent Performance Products' hitches are designed for use in light trucks such as the Ford F-Series, the Chevy Silverado and the Dodge Ram. Cequent Performance Products recommends the use of long bed (8ft) light trucks for the best combination in truck - trailer turning clearance.


Rule of thumb: The distance from the back of the truck cab to the center of the rear truck axle ("X" in Fig. 18), should be approximately 4 inches greater than one-half the trailer width ("Y" in Fig.18)

**Figure 18**



6. If a short bed pickup (less than 8 ft. but longer than 6 ft.) is to be used for towing, Cequent Performance Products recommends the trailer be equipped with a minimum 13" extended pin box to help gain additional truck - trailer turning clearance (See trailer manufacturer for options) (See Fig. 19).


**Figure 19**



**⚠ WARNING:** Do Not install this fifth wheel hitch on or attempt to tow with a short bed pickup truck that has a bed shorter than 6 ft. Unless you use a REESE Sidewinder or Revolution Pin Box. Doing so could result in vehicle damage, Serious injury, or Death.

7. The height of the hitch and the pin box should be adjusted so the trailer is approximately level as it is towed. Allow approximately 6 inches clearance between the top of the pickup walls and the underside of the front of the trailer for pitch and roll of the trailer. (See Fig. 20). For off road use allow more clearance between pickup walls and trailer.

**Figure 20**




**CAUTION:** The measurements above are guidelines. If your measurements are close to these numbers re-check clearances. If vehicle and/or trailer has any added bed vicinity accessories (i.e. fairings, air dams, ground effects, bed rails, etc.), additional dimensioning and clearance checks have to be made.

8. Hitch height determination:  
 With trailer leveled and on level ground measure from the ground to the king pin box, "A" in Figure 21. Secondly measure from the height of the inside of the truck bed, "B" in Figure 21. Dimensions "C" and "D" in Figure 21 can be used to determine the amount of clearance over the side rails, as mentioned in step 7.

$$\text{Hitch Height} = A - B + 2''$$

The 2" value is an estimate of suspension compression due to king pin weight of the trailer. This compression could range between 1"-5" depending on the truck being used and the trailer being towed.

$$D - C + 2'' > 6'' \text{ as stated in step 7.}$$



**Figure 21**

9. If a lube plate is to be used with a Elite Series 5<sup>th</sup> Wheel it must be at least 12" in diameter and not more than 3/16" thick. Cequent Performance Products offers this optional lube plate as part # 83001.

**⚠ WARNING:**



- Connection for trailer wiring must be located at the side of the truck bed between the driver's seat and the rear wheel to prevent operators from working between the truck and trailer.
- Avoid putting any part of your body under the trailer or between the truck and trailer. Unexpected or accidental movement of the truck or the trailer can cause serious injury or death
- If you must place any part of your body under the trailer or between the truck and trailer you **MUST** perform **ALL** of the following steps:
  - Check that the truck transmission is in park
  - Check that the emergency brake is set
  - Block in front of and behind all trailer tires
  - Check that the trailer landing gear are resting on firm ground

**HITCHING PROCEDURE:**

**IMPORTANT: YOU ARE RESPONSIBLE FOR SAFE HITCHING AND UNHITCHING OPERATIONS. DO NOT RELY ON OTHERS TO PERFORM THESE DUTIES. YOU MUST PERSONALLY MAKE SURE THE FOLLOWING STEPS ARE PERFORMED IN THE FOLLOWING ORDER!**


**⚠ WARNING:**  
**FAILURE TO FOLLOW THESE INSTRUCTIONS MAY RESULT IN DEATH OR SERIOUS INJURY.**

1. Place blocks (sometimes called “chocks”) firmly against front and rear of each trailer wheel to prevent any possible forward or rearward motion. DO NOT REMOVE BLOCKS UNTIL EACH OF THE FOLLOWING STEPS AND THE PULL TEST HAVE BEEN COMPLETED. Lower tailgate if necessary. Clearance of the lowered tailgate to the trailer needs to be monitored during hookups as some manufacturer combinations of truck and trailer have little or no clearance.
2. Using trailer jacks, adjust trailer height following the directions in the trailer manual so that bottom of trailer pin box (“A” in Figure 22) is ½ to 1 inch below skid plate (See “B” in Figure 22). During the hitching maneuver, the bottom of the trailer pin box should come in contact with skid plate ramp (“C” in Figure 22).




**⚠ WARNING:**  
 Failure to follow this instruction may result in king pin being too high and coming to rest on top of closed jaws or not completely inside jaw. (Figure 23). This could result in trailer separating from hitch. Trailer separation may result in death or serious injury if anyone is under the trailer or between truck and trailer when separation occurs.

3. Remove bail pin from bail pin hole (see Figure 24). Then pull handle out and rearward to hold open. Hitch jaw must be in the open position for king pin to enter the hitch.




4. With handle in the open position (See Figure 24), back truck slowly into trailer. As king pin completely enters head, jaw will spring closed around king pin and handle will return to the closed position. If the handle does not return to the closed position, then try to push the handle back to the closed position. If handle does not return to the closed position then move the truck slightly forward or rearward until the handle returns to the closed position. (See Figure 25)




5. Use only the method described above for hitching.

6. With all trailer wheels still firmly blocked, landing gear still resting on firm ground and supporting trailer weight, and truck stationary and in park with emergency brake on: visually check that bottom of pin box is resting on top of the hitch. THERE SHOULD BE NO SPACE BETWEEN THESE SURFACES (see Figure 26). If space exists, (see Figure 27) trailer has not been properly hitched. DO NOT TOW! Instead, repeat above steps until trailer is properly hitched. **DO NOT PLACE BODY UNDER TRAILER TO PERFORM THIS INSPECTION!**



7. Place bail pin through the bail pin holes in the handle and base plate to make sure the hitch jaw is locked closed. Pin must go through holes in **both** the handle and base plate. IF FLAG BLOCKS HOLE FOR BAIL PIN, TRAILER HAS NOT BEEN PROPERLY CONNECTED TO HITCH. DO NOT TOW! Repeat above steps until trailer is properly hitched. (see Figure 28)




8. With:

- All trailer wheels still firmly blocked in front and behind each tire, and
- Truck stationary with the emergency brake on, and
- Trailer landing gear still resting on firm ground and supporting trailer weight; and
- Truck stationary and with emergency brake on:

Connect electrical cable between truck and trailer, connect breakaway switch cable from pin box to a permanent part of truck, and raise tailgate of truck. **Do not tow trailer until the Pull Test has been successfully completed.**

**⚠ WARNING:**

Do not attempt to hitch by using trailer jacks to lower trailer and king pin. This could result in king pin coming to rest on top of skid plate instead of within hitch opening where jaws are located. King pin could slide off hitch and trailer could drop, resulting in death or serious injury (see Figure 29).



**Figure 29  
WRONG**

**⚠ WARNING:**

- Connection for trailer wiring should be in the side of the truck bed between the driver's seat and the wheel well for the back truck axle
- Installation of connection rearward of the wheel well may result in user placing body between truck and trailer. **WHENEVER POSSIBLE, AVOID PUTTING BODY UNDER TRAILER OR BETWEEN TRUCK AND TRAILER!**
- If you need to place any part of your body under trailer or between truck and trailer:

- All trailer tires **MUST** be blocked in front and behind each tire **AND**
- Trailer landing gear **MUST** be resting on firm ground **AND**
- Truck **MUST** be stationary, in park, with emergency brake on!

**PULL TEST**

**⚠ WARNING:**

Failure to perform pull test may result in death or serious injury

1. With all trailer wheels still firmly blocked, and
2. Trailer landing gear still resting on firm ground and supporting trailer weight and,
3. Truck stationary and with emergency brake on:
4. Make sure no one is between truck and trailer. Return to cab of truck and release truck's emergency brake. Apply trailer brakes. Try to pull trailer slowly forward with the truck. If the trailer is properly hitched, the wheel blocks and trailer brakes should keep the truck from moving forward.

NOTE: If trailer is not properly hitched, trailer will separate from hitch and truck will move forward leaving trailer behind. If you followed all previous steps, the trailer will not drop or fall.

**⚠ WARNING:**

Failure to keep wheels blocked and landing gear down could result in trailer suddenly moving or falling. This could result in death or serious injury!

5. After successfully performing above steps, fully raise trailer landing gear (see trailer manual).
6. Check and inspect all electrical circuits for proper operation. (Clearance lights, turn signals, stop lights, etc.).
7. Remove and store all trailer wheel blocks.

## **UNHITCHING PROCEDURE:**

### **PERFORM THE FOLLOWING IN THIS ORDER:**

1. Make sure truck is in park with emergency brake on.
2. Place blocks firmly against front and rear of each trailer wheel to prevent any possible forward or rearward motion.
3. Using trailer jacks, lower trailer landing gear following the directions in the Trailer Manual until feet of landing gear are resting on firm ground.

### **⚠ WARNING:**

Trailers that are not stable or properly hitched can fall and cause death or serious injury!  
To avoid death or serious injury:

- All trailer tires **MUST** be blocked in front and behind each tire **AND**
- Trailer landing gear **MUST** be resting on firm ground **AND**
- Truck **MUST** be stationary, in park, with emergency brake on!

4. Lower truck tail gate.
5. Disconnect power cable and breakaway switch cable between truck and trailer.
6. Remove bail pin from hole in handle.
7. Pull hitch handle out completely until it latches in open position so that king pin is no longer securely grasped by the hitch jaw (see Figure 24). Trailer is now free from hitch and truck. If handle does not pull out, there is probably pressure against the jaw. To relieve this pressure, back the truck slightly. Reset truck emergency brake. Then pull hitch handle out completely until it latches in open position.
8. **AFTER MAKING CERTAIN NO ONE IS STANDING BETWEEN TRUCK AND TRAILER OR IN FRONT OF TRUCK,** drive truck slowly away from trailer.

### **⚠ WARNING**

Whenever possible, avoid putting body under trailer or between truck and trailer  
If you need to place any part of our body under trailer or between truck and trailer:

- All trailer tires **MUST** be blocked in front and behind each tire **AND**
- Trailer landing gear **MUST** be resting on firm ground **AND**
- Truck **MUST** be stationary, in park, with emergency brake on!


9. Hitch jaw will automatically close as the king pin is removed from the jaw.
10. **KEEP WHEEL BLOCKS IN PLACE.** This will keep trailer from moving unexpectedly

## **MAINTENANCE:**

1. Recheck tightness of all hardware every 1000 miles of use. All 3/4" bolts have a torque specification of 260 ft.lbs., and 1" jam nuts should be box wrench snug plus 1/4 turn.
2. See "Before each trip" section in this manual.
3. Anchor assemblies should be lubed every 6 months with lithium grease to keep assemblies moving freely.
4. See "Lubrication Areas" section in this manual.

### **⚠ WARNING:**

Tilting 5<sup>th</sup> Wheel head can crush and cut. Keep hands and fingers clear from this area at all times (including placement/removal of head).



**Figure 30 : Head Placement**




Figure 31

REF #	QTY.	DESCRIPTION
1	1	HEAD ASSEMBLY
2	1	CENTER SECTION
3	2	BASE ARCH
4	1	HANDLE TUBE
5	1	HANDLE GRIP
6	4	3/4-10 GR8 HEX HEAD BOLT
7	4	3/4 LOCK WASHER
8	2	1/4-20 GR2 HEX HEAD BOLT
9	2	TUBE SPACER
10	2	TORSION SPRING
11	2	3/8 CARRIAGE BOLT
12	2	3/8 NUT
13	2	3/8 LOCK WASHER
14	2	1/2" PULL PIN
15	2	SPRING RETAINING CLIP
16	2	WASHER

REF #	QTY	DESCRIPTION
17	1	HANG TAG
18	4	ANCHOR, BUSHING
19	4	ANCHOR, TEE PIN
20	2	HANDLE, LT ANCHOR
21	2	HANDLE, RT ANCHOR
22	6	LYNCH PIN
23	4	1" NUT
24	1	BAIL PIN
25	1	LABEL, PINCH POINT
26	1	LABEL, OPERATING WARNING
27	1	LABEL, ANCHOR PIN
28	1	LABEL, WARNING
29	1	LABEL, RATING 1
30	2	#8-32x1 MACHINE SCREW
31	2	RUBBER BUMPER
32	2	#8-32 LOCK NUT

# **NOTES**

## **LIMITED LIFETIME WARRANTY**

### **Hitches - Custom Receivers**

Cequent Performance Products Inc. (“We” or “Us”) warrants to the original consumer purchaser only (“You”) that the product will be free from material defects in both material and workmanship, ordinary wear and tear expected; provided that installation and use of the product is in accordance with product instructions. There are no other warranties, express or implied, including the warranty of merchantability or fitness for a particular purpose. This warranty is not transferable.

This warranty does not cover: (a) normal wear and tear; (b) damage through abuse, neglect, misuse, or as a result of any accident or in any other manner; (c) damage from misapplication, overloading, or improper installation; (d) improper maintenance and repair; and (e) product alteration in any manner by anyone other than Us, with the sole exception of alterations made pursuant to product instructions and in a workmanlike manner.

To make a Warranty claim, contact Us, at our principal address of 47912 Halyard Dr. Suite 100, Plymouth, MI 48170, 1-800-632-3290, identify the product by model number, and follow the claim instructions that will be provided. Any returned product that is replaced by Us becomes our property. You will be responsible for return shipping costs. Please retain your purchase receipt to verify date of purchase and that You are the original consumer purchaser. The product and the purchase receipt must be provided to Us in order to process Your Warranty claim.

Product replacement is Your sole remedy under this Warranty. We shall not be liable for service or labor charges incurred in removing or replacing a product or any incidental or consequential damages of any kind.

You acknowledge and agree that any use of the product for any purpose other than the specified use(s) stated in the product instructions is at Your own risk.

This Warranty gives you specific legal rights, and You may also have other rights which vary from state to state. This Warranty is governed by the laws of the State of Michigan, without regard to rules pertaining to conflicts of law. The state courts located in Oakland County, Michigan shall have exclusive jurisdiction for any disputes relating to this warranty.

Cequent Performance Products, Inc.  
47912 Halyard Dr. Suite 100  
Plymouth, MI 48170